

## Setting Wake-up Calls on the Console

1. Press **GUEST RM** key
2. Enter **Room #** **ex. 200**
3. Press **ENTER** (F0 key)
4. Press **Wake-Ups** (F3 key)
5. Press **SET WAKE-UP** (F2 key)
6. Enter **Time** (4 digits in either 12 hour or 24 hour time) **ex. 0700**
7. Choose **AM** (F2) or **PM** (F3)
8. To **SET** press (F0 key)
9. Press **EXIT** (F1 key)

## Clearing/ Cancelling Wake-up Calls

1. Press **GUEST RM** key
2. Enter **Room #** **ex. 200**
3. Press **ENTER** (F0)
4. Press **Wake-Ups** (F3)
5. Press **CLEAR WAKE-UPS** (F7)
6. Press **EXIT** (F1)

## Setting Room Call Restrictions on the Console

1. Press **GUEST RM** key
2. Enter **Room #** **ex. 200**
3. Press **ENTER** (F0)
4. Press **STATUS** (F8)
5. Press **CALL REST** button (F4) – Look at the display and toggle the F4 key until you get to the call restriction status you want to set.

STATUS OPTIONS are as follows:

- Internal – Room to Room Calling Only
- Local
- Long Distance – Canada /US Calling Only
- Option 1 = Canada /US Calling Only
- Option 2 = Canada /US Calling Only
- Option 3 = Overseas calling

6. Press **SET** (F0)
7. Press **EXIT** (F1)