



MIVoice BUSINESS CONSOLE

Label Installation Guide

The MiVoice™ Business Console™ Operator will use keys on a standard PC keyboard to manage calls.

Please apply these labels to the PC keyboard(s) that operators will be using.

Application Instructions:

1. Ensure key surfaces are dry and clear of any debris, oil or grease. Key surfaces may be cleaned using Isopropyl Alcohol (rubbing alcohol).
2. Select the labels that best suit your users. Would they prefer English text or symbols?
3. Select the labels that best suit your keyboard. Note that the label for the Ctrl key has been provided in two sizes. If necessary, labels may be trimmed with scissors.
4. Carefully apply the selected labels to the keys as shown in the diagrams below. We recommend the use of tweezers.

Note: The label adhesive requires pressure to fully activate bonding. Ensure that you apply adequate pressure to each label after it is placed on a key.

The keyboard may be used immediately; however, allow 48-72 hours for the adhesive to fully cure before cleaning keyboard.

5. Store the remaining labels in a cool, dry location for future use.