

Mitel SX200 User Telephone Training

How Program Superkey to a Key

To program a feature key to be the Superkey:

1. Press **Settings** or Blue Applications Button.
2. Press **Programmable Keys**.
3. Press the key you wish to program.
4. If Applications are displayed, press **View Features**.
5. Use the Page Navigation keys to move through the features list.
6. Select **Superkey**.
7. Press **Save**.

Note: You cannot program a Superkey on keys 31 to 48 of the 5340 phone.

Call Forwarding

Call Forwarding lets you redirect incoming calls to an alternate number when your phone is busy, when you're not answering, or all the time. You can use the Settings key to set a global forwarding option for all calls, or to program a feature key with a desired forwarding method. If you need one forwarding setup for Internal calls and a different setup for External calls, use the Superkey to program Call Forwarding.

Programming Call Forward

To set a global Call Forward option for all calls:

5330 Phone:

1. Press the key that you have programmed as **Superkey**.
2. Press **No** until "Call Forwarding?" appears, if necessary.
3. Press **Yes** to select **External** or **Internal** calls.
4. Use the **Next** key to navigate through the Call Fwd categories (Always?, If Busy?, No Ans?, etc.) and then press **Pgm** to select.
5. Enter the number to which you want your calls forwarded and then press **Save**.

5340 Phone:

1. Press the key that you have programmed as **Superkey**.
2. Press the **More** key until the Forwarding option appears.
3. Press the **Forwarding** key.
4. Press the key for your desired forwarding option (Busy, Always, To me, No Ans)

NOTE: When you see TO: -- dial the destination number.

Destination numbers include:

- the voicemail pilot number (*8)
- another internal extension number
- a pre-defined system speed call (if call forward external is allowed)- *Usually turned off by default.*

Conference

To form a Conference when a two-party call is already in place, or to add another party to an existing Conference:

1. Press **TRANS/CONF** Key (caller is placed on hold)
2. Dial 9 + outside number or extension number of the next party.
3. Wait for an answer and announce conference.
4. Press (**TRANS/CONF** key again to join parties.

If you misdial, get voicemail, or do not wish to add Caller to the conference, press line key where your existing conference is on hold.

To leave a Conference:

- Hang up the handset or press **CANCEL** key.

System Park

To place a call on hold and retrieve from ANY extension on the system:

- With the caller on the line, press the **Call Park** key
- Watch and note the information from the display which shows where the call is parked.
- To retrieve the Parked Call press the button it is parked on

- If at console will need to dial call park code *57 xx (will be 01,02 or 03)

Call Pickup

To pick up a call ringing at another extension:

- Dial *09
- Dial ringing extension number

To pick up a call holding at another extension:

- Dial *23
- Dial extension number where call is holding

To pick up a call ringing at the switchboard:

- Dial *14

Setting up your Mailbox

Call Voicemail from your telephone by pressing your **Message** key or press *8

The default passcode is: **1 1 1 1**

Listen to the tutorial first time enrollment session which explains how to:

- 1 – Record a Greeting
- 2 – Record your Name
- 3 – Change your temporary passcode (4 to 10 digits)

Your mailbox number is your 4-digit extension number

Checking your Messages

If you have messages, the **red** bar on the top of the phone will be lit

To check your messages:

- Press your **Message** key or press *8
- Enter your **passcode**

