

MITEL 5340 IP PHONE



Ouick Reference Guide

- Display
- Ring/Message Indicator
- Volume, Speaker, Mute Controls
- Fixed Function Keys
- Keypad
- Page Navigation Keys
- Programmable Feature Keys and Softkeys
- Speaker Message
- Handset



Speaker



Mute



Menu



Cancel



Redial





→ Image: A conference of the conference of



NOTE: For more information about using other features and applications on your 5340 IP Phone, refer to 5330/5340 IP Phone User Guide located at www.mitel.com, or contact your Administrator. **SIP Users:** Refer to the 5330/5340 SIP User and Administrator Guide.

Make a Call

- Lift the handset OR
- 3 Press (1) .
- 5 Dial the number OR
- 7 Press a Speed Call key OR
- 4 Press 123.5 OR
- 5 Dial the prefix for external calls (e.g. 9) and the number.

Answer a Call

- Lift the handset OR



, and begin speaking.

End a Call

- 4 Press X OR
- Replace the handset.

Place a Call on Hold

- ◆ Press △ ← . The line keyflashes.
- Replace the handset if necessary.

Retrieve a Call from Hold

- Lift the handset OR
- Press (1).

Retrieve a Message

4 Press . It flashes when a message is waiting.

Follow the voice mail prompts to retrieve your message.

Transfer a Call

- 4 Press $\sim \mathfrak{M}$.
- 5 Dial the number. Wait for an answer.
- Hangup OR wait for the called party to answer, announce the transfer, and then hang

Conference a Call

- 4 Press ~ 90
- 5 Dial the number of the next party. Wait for an answer.
- 4 Press A M.

Program a Speed Call

4 Press Menu OR

Press Settings.

Press Programmable Keys.

Press the key you wish to program.

Press Speed Call.

Press Edit Info and enter the label for the Speed Call.

Press Save.

Press Edit Number and enter the phone number for the Speed Call.

Press Save, and then press Save again.

Press Close and then press Close again.

Adjust Volume Levels

Adjust ringer volume while the phone is ringing.

Adjust handset or speaker volume while using the handset or speaker.

3 Press repeatedly to raise the volume OR repeatedly to lower the volume.

3 Press 💆 to mute your microphone.





Voicemail Set-Up

Accessing Your Mailbox

All of your voice messages will reside in your personal mailbox, which is passcode protected. Your temporary passcode will be 1111 to use the first time you access your mailbox. How you log into your mailbox will depend on whether you're calling from inside or outside your company.

From Your Own Extension

- Press the (MESSAGE) key on the Mitel phone
- Enter your passcode when prompted.

From Another Extension

- Press the (MESSAGE) key on the Mitel phone
- Press the * key when prompted to enter a passcode
- Enter your mailbox number followed by the * key.
- Enter your passcode when prompted.

Note: You may need to use this procedure to access a general mailbox when the lamp is inactive.

Setting Up Your Mailbox

When you access your mailbox for the first time, a user tutorial automatically activates. This tutorial guides you through your first mailbox session, explains how to record a greeting and your name, and prompts you to change your temporary passcode.

Passcode

You will always be prompted for your passcode before accessing your mailbox. The first time you access your mailbox, you will use the temporary
passcode 1111. During the tutorial, you will be prompted to change your passcode to a number containing 4 to 10 digits. Define a passcode that you
can easily remember, but do not select an obvious code like "1234".

Greeting

- After opening your mailbox, you will be asked to record a greeting that callers will hear when they are directed to your mailbox.
- e.g. "You have reached the mailbox of Steve Smith, I'm unable to take your call, please leave me a message with your contact details and I will return your call when I am available."

Name

- You will be prompted to record your name
- The system will use this name to identify you to callers in your own voice.

Playing Messages

When you access your mailbox to retrieve your messages, the system tells you how many messages you have ("You have 2 urgent messages and 2 unplayed messages.").

Playing Your Messages

After accessing the Voice Mail menu, press 7 to listen to your messages. Your urgent messages will automatically be played first. Then, your unplayed messages will be played.